


FIP_SW:
 0 = KEYFOB DOCKED
 1 = KEYFOB REMOVED
 CHARGERSTAT:
 0 = KEYFOB CHARGING
 1 = FULLY CHARGED



CANNOT USE ISP CONNECTOR WHEN USING USB

Reset Generator and Supervisor
 Reset Theshold = 2.63V

RETURN TO FACTORY DEFAULT

PLACE 32.768kHz AS CLOSE TO CHIP AS POSSIBLE

ember
 313 Congress Street
 Boston, MA 02210
 4th Floor

Title: **AVR**

Size	Document Number	Rev
	SCH0330	C0

Date: Friday, September 24, 2004 Sheet 3 of 8